




艾歐格

P5&P-MOVE充电座


产品说明书(PG-P5011)



产品特点:

- 1. 本产品适用于P5和P-MOVE游戏手柄进行充电使用;
- 2. 支持双手柄充电功能, 更好的节约空间及电源设备;
- 3. 具有充电及饱和指示功能, 清晰直观的了解当前充电状态;

产品概览:




电性参数:

- 1..工作电压: DC 4.8 - 5.2V;
- 2.允许充电电流: <600 mA(单个手柄) ;

产品使用说明:

- 1 .将产品接入DC5V 2A电源适配器或游戏主机USB接口, 产品电源指示灯亮起;

- 2 .将P5或P-MOVE手柄对应充电口插入充电座后, 等待3秒左右, 相对应的充电状态指示灯会由蓝色转变为红色, 此时手柄为充电状态; 当手柄充满后红色指示灯转变为蓝色, 此时手柄为饱和状态;



连接DC5V 2A电源

注意事项:

- 1: 使用本产品时需配套使用标准带有保护功能的电源适配器, 以防发生意外损坏产品及手柄;
- 2: P5/P-MOVE手柄快充满电时, 本产品充电指示灯存在与P5主机或手柄提示不同步的现象, 此为正常现象;
(例如: P5/P-MOVE手柄充电指示已经指示充满, 但是进入P5/P-MOVE主机查看依然在充电)
- 3: P5/P-MOVE手柄电池低压被保护后, 插入本产品充电, 指示灯会不同步, 此为正常现象;
(例如: P5/P-MOVE手柄电池低压被保护后, 插入产品进行充电, 充电指示灯短时间内依然显示蓝色或者蓝色与红灯之间闪烁)
- 4: 在4个手柄都完全没电的情况下, 请将手柄逐一插入充电座充电。


产品清单:



充电座 x1



说明书 x1




Type-C USB线 x1



CHARGE STATION FOR P5 & P-MOVE


Product Manual(PG-P5011)



Features:

- 1.The charging station used for P5 and P-MOVE controller .
- 2.Support two P5 controllers and two P-MOVE controllers charging at same time , saving space and power .
- 3.With charging saturation indication function, showing the current charging status clearly.

Product appearance illustration:




Product parameter:

Working voltage: DC4.8V - 5.2V;
input current : <600 mA(single controller);

Product instructions:

- 1.Connect the product to the DC5V 2A power adapter or game console with USB port , the power indicator will lights up.
- 2. Insert the P5 or P-MOVE controller into the corresponding interface of the charging stand, wait for about 3 seconds, the corresponding charging indicator will change from blue to red, now the controller under charging state; when controller fully charged ,the red indicator will turn red to blue.



Connect to DC5V 2A power

Notes:

- 1. When using this product, need a standard power adapter with protection function to prevent accidental damage to the product and controller;
- 2. When P5 and P-MOVE controller fully charged , the indicator of this products , will be inconsistent with the prompt of the P5 console or controller, this is a normal phenomenon.(Example :P5/P-MOVE controller charging indicator showing full, but the P5/P-MOVE console still showing charging)
- 3. After the low voltage of the P5/P-MOVE controller battery is protected, insert the product to charge, the indicator light will be inaccurate, this is normal phenomenon.
(Example :After the low voltage of the P5/P-MOVE controller battery is protected, insert the product to charge,the charging indicator still shows blue or flashes between blue and light color for a short time)
- 4.Please insert the controllers into the dock one by one for charging when the 4 controllers are all run out of battery.

Included:



Charge Station X1



User Manual x1



Type-C USB cable

Patent NO. : ZL202030261595.2